



musher[®]
FREEDOM · ALLIES

HASZNÁLATI ÚTMUTATÓ

Musher Freespirit rugalmas szár

Biztonsági figyelmeztetés:

- Minden használat előtt ellenőrizzük a termék épségét! A sérült vagy elhasználódott termék balesetveszélyes lehet, használatát nem javasoljuk.
- Mindig ügyeljünk arra, hogy a rugalmas szár ember felőli végén ne maradjon karabiner, mert a megfeszített szár elengedése esetén kárt okozhat a környezetben, vagy a kutyában!

A termék rendeltetésszerű használata:

1. A rugalmas szárat a két csat segítségével állítsuk a kívánt hosszúságúra.
2. A rugalmas szár karabinerrel nem rendelkező végét akasszuk az övön található karabinerbe. Ha nem használunk övet, akkor fogjuk kézben.
3. A rugalmas szár forgó karabineres végét akasszuk a kutya hámjának erre kialakított részébe (Musher hámok esetén a hámbecsatolási pontján lévő zöld madzagkarikába)
4. Használat után száraz, tűző napfénytől védett helyen tároljuk

Tisztítás és ápolás:

Langyos, szappanos vízben kézzel mosható.

Ne használjunk erős vegyszert!

A fém karabinert mosás előtt vegyük le.

Szárítógéppel és tűző napon történő szárítás tilos!



musher[®]
FREEDOM · ALLIES

USER GUIDE

Musher Freespirit flexible leash

Safety warning:

- Always check the integrity of the product before each use. Using a damaged or worn product may cause accidents and is therefore not recommended.
- Always make sure that there are no carabines left on the end held by the person, as releasing the leash while taut may damage the dog or others.

Proper use of the product:

- Adjust the leash to the appropriate length using the two buckles.
- Attach the end of the leash containing no carabiner to the carabiner on the belt. When not using a belt, hold it in hand.
- Attach the end of the leash with the carabiner to the appropriate connecting point on dog's harness (in case of Musher harnesses, this is the green cord loop near the buckling point).
- After use, store the product in a dry area protected from direct sunlight.

Cleaning and maintenance:

May be washed manually in lukewarm water with soap.

Do not use potent chemical products.

Remove the metal carabiner before washing the product.

Never dry the product in the hot sun or using a drier.