



**musher**<sup>®</sup>  
FREEDOM · ALLIES

## HASZNÁLATI ÚTMUTATÓ

### Musher Koyuk / Musher Anvik 2 kutyás rugalmas szár

Biztonsági figyelmeztetés:

- A termék épségét minden használatba vétel előtt ellenőrizzük! A sérült vagy elhasználódott termék balesetveszélyes lehet, használatát nem javasoljuk
- Mindig ügyeljünk arra, hogy a rugalmas szár ember felőli végén ne maradjon karabiner, mert a megfeszített szár elengedése esetén kárt okozhat a környezetben, vagy a kutyában!
- Kössük össze a kutyákat nyakszárral. Ennek hiányából esetlegesen adódó termék sérülésért a gyártó nem vállal felelősséget.

A termék rendeltetésszerű használata:

1. A rugalmas szár karabinerrel nem rendelkező végét akasszuk az övön található karabinerbe. Ha nem használunk övet, akkor fogjuk kézben.
2. A rugalmas szár forgó karabineres végeit akasszuk a kutyák hámjainak erre kialakított részeibe (Musher hámok esetén a hámbecsatolási pontján lévő zöld madzagkarikába).
3. Használat után száraz, tűző napfénytől védett helyen tároljuk.

Tisztítás és ápolás:

Langyos, szappanos vízben kézzel mosható. Ne használjunk erős vegyszert! Szárítógéppel és tűző napon történő szárítás tilos!



**musher**<sup>®</sup>  
FREEDOM · ALLIES

## USER GUIDE

### Musher Koyuk / Musher Anvik flexible leash for 2 dogs

#### Safety warning:

- Always check the integrity of the leash before each use. Using a damaged or worn product may cause accidents and is therefore not recommended.
- Always make sure that there are no carabines left on the end held by the person, as releasing the leash when taut may damage the dog or others.
- Use a neck strap to hitch the dogs together. The manufacturer accepts no responsibility for damages to the product that result from failing to do so.

#### Proper use of the product:

1. Attach the end of the leash containing no carabiner to the carabiner on the belt. When not using a belt, hold it in hand.
2. Attach the end of the leash with the carabiner to the appropriate connecting point on dog's harness (in case of Musher harnesses, this is the green cord loop near the buckling point).
3. After use, store the product in a dry area protected from direct sunlight.

#### Cleaning and maintenance:

May be washed manually in lukewarm water with soap.

Do not use potent chemical products.

Never dry the product in the hot sun or using a drier.